Spare parts

Awning post base

To replace the parts highlighted in the drawing below (AWB caps) in case of loss or damage, order the codes indicated in the following table:

Type	Replacement parts code
AWB40 (silver)	AWB40-CAP
AWB40_N (black)	AWB40_N-CAP
AWB60 / AWB60A (silver)	AWB60-CAP
AWB60_N / AWB60A_N (black)	AWB60_N-CAP
AWB40X / ST42BX-S / ST42BAX-S	AWB40X-CAP
AWB60X / AWB60AX	AWB60X-CAP
AWB60 SF	AWB60 SF-CAP
AWB80X	AWB80X-CAP
AWB80	AWB80-CAP
AWB100	AWB100-CAP
AWB80 T	AWB80 T-CAP
AWB100 T	AWB100 T-CAP



Spare parts

Awning post base

AWB40-CAP
AWB40_N-CAP
AWB40X-CAP



AWB60-CAP
AWB60_N-CAP
AWB60X-CAP



AWB80X-CAP



AWB60 SF-CAP



AWB80-CAP



Spare parts

Awning post base

AWB100-CAP



AWB80 T-CAP



AWB100 T-CAP